STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

SANKT-PETERBURG, RUSSIA
PULKOVO
RNAV RWY 10L, 10R



APPROACH	Sector 1	(EAST)	H24	119.300
	Sector 2	(WEST)	0600-1600	125.200
	Sector 2	(WEST)	1600-0600	119.300
KRUG				120.300
TOWER	RWY 28R			118.100
TOWER	RWY 28L			118.700

❶ TRANSITION LEVEL:
- FL050 when QNH is 747mm mercury column or above;
- FL060 when QNH is 720mm mercury column or above, but less than 747mm mercury column;
- FL070 when QNH is less than 720mm mercury column.

WARNING:
1. Descent shall be carried out only by ATS unit instruction.
2. The flight crews shall advise ATS unit if unable to adhere to altitude (flight level) or speed restrictions.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS ARE IN *FEET*
DISTANCES ARE IN KILOMETRES

CHANGE: New chart