# STANDARD ARRIVAL CHART INSTRUMENT (STAR) - ICAO

TRANSITION LEVEL : ❶

# SANKT-PETERBURG, RUSSIA
## PULKOVO
## RNAV RWY 28L, 28R




| | | | | |
|---|---|---|---|---|
| APPROACH | Sector 1 | (EAST) | H24 | **119.300** |
| | Sector 2 | (WEST) | 0600-1600 | **125.200** |
| | Sector 2 | (WEST) | 1600-0600 | **119.300** |
| KRUG | | | | **120.300** |
| TOWER | RWY 28R | | | **118.100** |
| TOWER | RWY 28L | | | **118.700** |

❶ TRANSITION LEVEL:
- FL050 when QNH is 747mm mercury column or above;
- FL060 when QNH is 720mm mercury column or above, but less than 747mm mercury column;
- FL070 when QNH is less than 720mm mercury column.

**WARNING:**
1. Descent shall be carried out only by ATS unit instruction.
2. The flight crews shall advise ATS unit if unable to adhere to altitude (flight level) or speed restrictions.

BEARINGS AND TRACKS ARE MAGNETIC
ALTITUDES AND ELEVATIONS ARE IN *FEET*
DISTANCES ARE IN KILOMETRES

**CHANGE:** New chart